

Keyframe Bedding Tool

Instructions for using the Keyframe Bedding tool to adjust the glide bolt to the correct height. With this tool the job should only take about 5 minutes.

1. Back off the glide bolt so they are not touching the keybed.
2. Make sure the end blocks are in place and tightened.
3. Check the bedding of the front and rear of the keyframe to keybed.
4. Starting at the center glide bolt, place the Keyframe Bedding tool next to the glide bolt to be adjusted.
 - Make sure the dial is against the pinblock.



5. Lower the center glide until the needle just starts to move. If you go too far just turn the glide backward until the needle stops.
 - The object is to have the glide just touching the keybed for support.
6. Now move to the Keyframe Bedding tool to the next glide bolt closest to the center and adjust the glide bolt.
7. Now move to the next glide closest to the center and so on.
 - The idea here is to start in the middle and work your way to the outer sides.